

SD-10G AERO

Procedure for programming a Sick Switch for Start-Stop operation of the Timer function of the SD-10G Transmitter.

Select **SYSTEM** using the Navigation Pad. Press **ENTER**.

Scroll down using the Navigation Pad and highlight **TIMER**. Press **ENTER**.

Highlight **Stop Watch** and press **ENTER**.

Set your desired **Minutes** and **Seconds** using Navigation Pad and the YES/+ key.

Press the **END** key three times.

Highlight **SYSTEM** and press the **ENTER** key.

Scroll down using the Navigation Pad to **SWitch ASSIGN**. Press **ENTER**.

Scroll down to **START**. Use the YES/+ key to set **START** to **S1** and set **STOP** to **S2**.

Press the **END** key twice. Press the **ENTER** key to access the **SYSTEM** menu.

Scroll down to **STICK SWITCH** and press the **ENTER** key.

STICK SWITCH >1

Set **STICK >TH** using the Navigation Pad and Yes/+ key. Move the Throttle stick UP slightly so **STICK** reads **-91%**. Highlight **POINT**. Press the YES/+ key to make it read **POINT > -91%**. This is the **ON** point for the Timer. With the **THROTTLE STICK** down in the extreme **LOW** throttle position, move the cursor down to **ON>H**. If it does not read **ON >H**, press the YES/+ key.

The display should indicate:

STICK >TH
POINT > -91%
ON > H
Sound > INH

The chart on the right side will indicate:

STICK
-100%
SW
OFF

Use the Navigation Pad and YES/+ key to select **STICK SWITCH 2**

Set the **POINT -91%** as done previously. However, when the Throttle Stick is at the extreme **LOW** position, scroll down and set it to read **ON >L**. With the Throttle Stick down in the extreme **LOW** throttle position the display should indicate:

STICK > TH
POINT > -91%
ON >L
SOUND > INH

The chart on the right side will indicate:

STICK
-100%
SW
ON

If it does not indicate **ON >L**, highlight it using the Navigation Pad and press the YES/+ key. Press the **END** key twice to return to the main display.

Your Timer Minutes and Seconds are shown on the **LCD Display**.

When you move the **THROTTLE STICK** above **-91%** The **Timer** will start. When you move it to the **LOW Throttle** position the Timer will stop. When the Timer counts down and reaches 10 seconds it will sound a note at each second and a final note when it reaches zero seconds and begin counting up. After the completion of your flight press the YES/+ and NO/- keys simultaneously to reset the time to your start time.

Jack R. Albrecht
Airtronics Technical Support
22 June 2009